



No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handleshaftretainer	104	"E" washer	199	Spool washer
14	Handle shaft cover	106	Alarm lever screw	202	Handle knob screw
54	Drag washer	107	Haness lugs screw	210	Reel foot screws
55	Fixed screw	109	Cover screw	211	Stopping bracket screw
58	Drag control lever arm	111	Alarm spring	212	Side plate screws
73	Alarm lever	114	Soundnail spring	214	Spool drag screw
74	Drag tension knob	115	Alarm lever base	220	Stoppingbracketspring
77	Ball bearing	117	Left side plate	222	Spool shaft spring
81	Front plate	118	Frame	223	Drag control lever washer(B)
82	Spool	119	Right side cover	226	Sound slice
83	Pressure plate	142	Reel foot	227	Dragcontrol lever thrust ring
84	Holder nut	159	Drive shield	256	Handle knob
85	Drive shaft cover	163	Drive shaft washer	319	Dial washer
86	Pre-program screw	164	Washer	477	Handle arm
87	Pre-program key	165	Fixed nuts	478	Drive shaft
90	Alarmlevercrosspinsupport	168	Soundnail	479	Drive gear-high speed
91	Alarm hammer	172	Limited spring	480	Drive shaft screw
93	Eccentric	177	Anti reverse dog	481	Handle bolt
94	Limited bushing	178	Sound plate screw	483	Stopping slice
95	Limited nail	182	Spool nail	581	T handlenail
98	Harness lugs	186	Thrust washer	602	Handleshaft fixed screw
100	Lever hub cover	187	"E" washer	720	Anti-reverse ratchet
101	Low speed pinion gear	191	Stopping bracket	723	Wrench
102	Alarm sound slice	195	Rod clamp		
103	Friction washer	198	Spool spring washer		