



No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handle shaft retainer	177	Anti reverse dog	225	Spacer
95	Limited nail	178	Sound plate screw	226	Sound silce
104	"E" washer	182	Spool nail	227	Dragcontrol lever thrust ring
112	Limited spring	183	Harness lugs	228	Alarm limited coat
114	Soundnailspring	186	Thrust washer	229	Alarm lever base
139	Spool	187	"E" washer	232	Drag control lever
141	Fixed screw	188	Eccentric	234	Drag washer
142	Reel foot	191	Stopping bracket	236	Alarmsupport
144	High speed pinion gear	195	Rod clamp	239	Drag control lever cap
145	Frame	198	Spool spring washer	240	Left side plate
146	Alarm lever cap	199	Spool washer	241	Right side cover
147	Drag control lever	200	Alarm sound slice	255	Handle knob
148	Alarm lever slice	201	Friction washer	313	Drive shaft spring
154	Handle shaft cover	202	Handle knob screw	319	Dial washer
155	Drag tension knob	203	Alarm washer	382	Ball bearing
159	Drive shield	204	Side plate screws	477	Handle arm
160	Leverhub cover	205	Haness lugs screw	480	Drive shaft screw
161	Drive shaft cover	207	Shaft screw	481	Handle bolt
163	Drive shaft washer	208	Crosspinfixedscrew	482	Drive shaft
164	Ratchet washer	209	Alarm lever screw	483	Stopping slice
165	Fixed nuts	210	Reel foot screws	484	Drive gear-high speed
166	Cover screw	211	Stopping bracket screw	527	T handenail
167	Pre-program screw	212	Side plate screws	529	Handle shaft coat washer
168	Soundnail	214	Spool drag screw	544	Pressure plate
171	Crosspinsupport	218	Alarm lever spring	717	Handle shaft fixed screw
172	Pre-program key	219	Alarm spring	720	Anti-reverse ratchet
173	Limited bushing	220	Dog spring	723	Wrench
174	Alarm lever crosspin support	222	Spool shaft spring		
175	Alarm hammer	223	Drag control lever washer(B)		
176	Alarm crosspin support	224	Pre-program plate washer		