



No.	PARTSNAME	No.	PARTSNAME	No.	PARTSNAME
10	Handle shaft retainer	186	Thrust washer	226	Sound slice
95	Limited nail	187	"E" washer	227	Dragcontrol lever thrust ring
104	"E" washer	188	Eccentric	228	Alarm limited coat
112	Limited spring	189	Reel foot	229	Alarm lever base
114	Soundnailspring	191	Stopping bracket	232	Drag control lever
146	Alarm lever cap	195	Rod clamp	234	Drag washer
147	Drag control lever	197	High speed pinion gear	236	Alarmsupport
148	Alarm lever slice	198	Spool spring washer	239	Drag control lever cap
149	Spool	199	Spool washer	240	Left side plate
154	Handle shaft cover	200	Alarm sound slice	241	Right side cover
155	Drag tension knob	201	Friction washer	242	Frame
159	Drive shield	202	Handle knob screw	255	Handle knob
160	Leverhub cover	203	Alarm washer	313	Drive shaft spring
161	Drive shaft cover	204	Side plate screws	319	Dial washer
163	Drive shaft washer	205	Haness lugs screw	382	Ball bearing
164	Ratchet washer	207	Shaft screw	477	Handle arm
165	Fixed nuts	208	Crosspinfixedscrew	480	Drive shaft screw
166	Cover screw	209	Alarm lever screw	481	Handle bolt
167	Pre-program screw	210	Reel foot screws	482	Drive shaft
168	Soundnail	211	Stopping bracket screw	483	Stopping slice
171	Crosspinsupport	212	Side plate screws	484	Drive gear-high speed
172	Pre-program key	213	Fixed screw	527	T handlenail
173	Limited bushing	214	Spool drag screw	529	Handle shaft coat washer
174	Alarm lever crosspin support	218	Alarm lever spring	544	Pressure plate
175	Alarm hammer	219	Alarm spring	552	Fixied nuts
176	Alarm crosspin support	220	Dog spring	717	Handle shaft fixed screw
177	Anti reverse dog	222	Spool shaft spring	720	Anti-reverse ratchet
178	Sound plate screw	223	Drag control lever washer(B)	723	Wrench
182	Spool nail	224	Pre-program plate washer		
183	Harness lugs	225	Spacer		